

Uploading Custom Tone Files to Algo SIP Endpoints

Need Help?

(604) 454-3792 or support@algosolutions.com



Introduction

Algo SIP endpoints which are capable of playing audio or sending audio via multicasting, are pre-loaded from the factory with several audio files in their internal memory for loud ringing applications. Users may also record or upload custom audio files, music, sound effects, or voice announcements for other types of notification (e.g. safety, security, emergency, customer assistance, shift changes, etc.). This guide covers the steps for uploading ringtones to the Algo SIP devices.

Requirement:

- 1.) Algo IP endpoint with firmware version 3.X or later
- 2.) The audio file format mp3 or wav
- 3.) Maximum upload file size at one time is 200MB



Uploading Custom Audio Files

- 1. To access the endpoint's web interface, open the web browser, enter the device's IP address in the address field, and press Enter.
- 2. Navigate to System -> File Manager tab -> tones folder.
- 3. Upload the file, either by dragging & dropping or using the Upload button.
- 4. Browse to the file local in the local computer.
- 5. Confirm the audio file play correct after upload by navigating to Basic Settings -> Features tab. Select the file from the Ring/Alert Tone dropdown box and click Play.

